SAMSUNG ELECTRONICS

© Samsung Electronics Co.,Ltd. SEP. 2001
Printed in Korea
AD68-00420E

SAMSUNG

SERVICE MANUAL

VP-D73/D73i/D75/D75i/D76/D76i/D77/D77i/SCD73/D75/D77

SAMSUNG

DIGITAL VIDEO CAMERA

VP-D73/D73i/D75/D75i/D76/D76i/
D77/D77i
SCD73/D75/D77

SERVICE Manual

For mechanical disassembly and adjustment, refer to the "Mechanical Manual" (CSM-2000 ⟶ AD68-00420B).

DIGITAL VIDEO CAMERA



CONTENTS

1. Specifications

2. Disassembly and Reassembly

3. Alignment and Adjustment

4. Exploded View and Parts List

5. Electrical Parts List

6. Wiring Diagram

7. PCB Diagrams

8. Schematic Diagrams